

Low electrical conductivity, inhibited propylene glycol/water-based coolant

Process Applications

- Coolant for PEM fuel cells
- Computer cooling
- Optical devices
- Electronics cooling
- Process cooling & heating
- Medical devices
- Portable fuel cell systems
- Battery cooling
- Charging stations

■ Dynalene LC-PG Overview

Dynalene LC-PG (propylene glycol-based) is specially designed for cooling PEM fuel cells, electronics, computers, and other applications requiring low electrical conductivity coolants. It provides efficient heat transfer that prevents your system from overheating while simultaneously acting as an electrical insulator. LC products use a non-ionic corrosion inhibitor package that prevents corrosion and contaminants from degrading your system.

Dynalene LC-PG is a customizable coolant that can be formulated using any concentration of propylene glycol that your system requires. Our LC-PG blends are non-flammable and non-toxic.

■ Corrosion Protection

Dynalene LC-PG utilizes a non-ionic corrosion inhibitor package that offers superior corrosion protection for most metals, including aluminum, brass, copper, stainless steel, and many other alloys. The inhibitors create a passive layer on metal surfaces in contact with the fluid, preventing corrosion and ion-leaching, which can cause an increase in electrical conductivity.

■ Benefits of Choosing Dynalene LC-PG

- Maintains low electrical conductivity
- Uses non-ionic corrosion inhibitor package
- Can be used with active deionizing systems
- Non-toxic
- Available worldwide
- Proven performance
- Total fluid care option
- Non-flammable
- Cost-effective
- Enhances fuel cell performance

■ Dynalene's Fluid Care Program

Coupling our Dynalene fluids with a fluid care program can extend the life of your systems significantly. We offer yearly testing of the heat transfer fluid in your system and can track changes in the fluid year to year so adjustments can be made to keep your systems working at its best.

Recommended Temperature Range:

For closed systems:

-50°C (-58°F) to 93°C (200°F)

■ Properties of Dynalene LC-PG

A comprehensive list of all thermo-physical properties of Dynalene LC-PG can be found on pages 2-5. For health and safety information or to request a Safety Data Sheet, contact our Dynalene sales representatives.

Composition:	Propylene glycol, water, non-ionic inhibitors
Appearance:	Clear
Odor:	None
pH:	Not applicable for low-conductivity fluid
Electrical conductivity:	< 5 µS/cm
Flash Point:	None*
Autoignition Temp:	None*

* for ≤ 85% concentration

■ Dynalene's De-ionizing Cartridges

Dynalene recommends using a de-ionizing cartridge with our LC products. Corrosion inhibitors prevent significant corrosion, but cannot guarantee 100% prevention. In a low-conductivity environment, even a small amount of corrosion can generate enough ions to raise the conductivity to unacceptable levels. A de-ionizing cartridge removes these ions to maintain the desired electrical conductivity. Contact Dynalene for information about the de-ionizing cartridges we offer.

■ Quantity & Availability

Dynalene LC products are offered in 1, 2.5, 5, 30, 55, and 265-gallon containers. Pricing depends on quantity, and Dynalene, Inc. will work with you to try to fit your budget.

General Properties

Vol. % LC-PG	Wt. % LC-PG	Freeze Point		Burst Point		Boiling Point °F	Specific Gravity 22°C (72°F)
		°F	°C	°F	°C		
0	0.0	32	0	32	0.0	212	1.000
5	5.2	29	-1.7	27	-2.7	212	1.005
10	10.5	26	-3.3	22	-5.6	212	1.010
15	15.6	23	-5.0	19	-7.5	212	1.015
20	20.8	19	-7.2	11	-11.8	213	1.020
25	25.9	14	-10.1	-1	-18.4	214	1.025
26	27.0	13	-10.6	-4	-20.1	214	1.026
27	28.0	12	-11.1	-7	-21.8	214	1.027
28	29.0	10	-12.2	-10	-23.6	215	1.028
29	30.1	9	-12.8	-14	-25.5	216	1.029
30	31.1	8	-13.3	-18	-27.5	216	1.030
31	32.1	7	-13.9	-21	-29.6	216	1.031
32	33.1	5	-15.0	-24	-31.1	216	1.032
33	34.1	4	-15.6	-30	-34.4	216	1.032
34	35.1	2	-16.7	-38	-38.9	217	1.033
35	36.1	1	-17.2	-46	-43.3	217	1.034
36	37.2	-1	-18.3	-53	-47.2	217	1.035
37	38.2	-3	-19.4	< -60	< -51.1	218	1.036
38	39.2	-4	-20.0	< -60	< -51.1	218	1.037
39	40.2	-6	-21.1	< -60	< -51.1	219	1.038
40	41.2	-8	-22.2	< -60	< -51.1	219	1.039
41	42.2	-10	-23.3	< -60	< -51.1	219	1.040
42	43.2	-12	-24.4	< -60	< -51.1	219	1.041
43	44.2	-14	-25.5	< -60	< -51.1	219	1.042
44	45.2	-16	-26.7	< -60	< -51.1	220	1.043
45	46.2	-18	-27.8	< -60	< -51.1	220	1.044
46	47.2	-21	-29.4	< -60	< -51.1	220	1.045
47	48.2	-23	-30.6	< -60	< -51.1	221	1.046
48	49.2	-26	-32.2	< -60	< -51.1	221	1.047
49	50.2	-28	-33.3	< -60	< -51.1	222	1.048
50	51.2	-31	-35.0	< -60	< -51.1	222	1.049
55	56.2	-46	-43.3	< -60	< -51.1	223	1.052
60	61.2	< -60	< -51.1	< -60	< -51.1	225	1.055
65	66.1	< -60	< -51.1	< -60	< -51.1	227	1.057
70	71.0	< -60	< -51.1	< -60	< -51.1	230	1.057
80	80.8	< -60	< -51.1	< -60	< -51.1	246	1.059
90	90.4	< -60	< -51.1	< -60	< -51.1	270	1.056

1 cP= 0.001 Pa·s

Viscosity (cP)

Temp, °F	Glycol percent by volume								
	20%	25%	30%	35%	40%	45%	50%	55%	60%
-30									498
-20									299
-10							96.0	140	183
0					40.9	51.1	61.3	88.2	115
10			13.4	20.2	27.0	33.8	40.6	57.4	74.2
20	5.36	7.63	9.89	14.2	18.5	23.2	27.8	38.6	49.3
30	4.23	5.85	7.46	10.3	13.1	16.4	19.7	26.7	33.7
40	3.41	4.58	5.75	7.68	9.60	12.0	14.3	19.0	23.7
50	2.79	3.66	4.52	5.87	7.21	8.96	10.7	13.9	17.1
60	2.32	2.97	3.62	4.59	5.56	6.85	8.13	10.4	12.6
70	1.95	2.45	2.94	3.66	4.38	5.36	6.34	7.93	9.51
80	1.66	2.05	2.43	2.98	3.52	4.28	5.04	6.19	7.34
90	1.43	1.74	2.04	2.46	2.88	3.48	4.08	4.93	5.77
100	1.25	1.49	1.73	2.07	2.4	2.88	3.35	3.99	4.62
120	0.97	1.14	1.30	1.52	1.73	2.05	2.36	2.74	3.11
140	0.78	0.90	1.01	1.16	1.31	1.53	1.75	1.99	2.22
160	0.64	0.73	0.82	0.93	1.04	1.20	1.35	1.51	1.66
180	0.54	0.61	0.68	0.77	0.85	0.97	1.08	1.19	1.29
200	0.46	0.52	0.58	0.65	0.71	0.80	0.88	0.96	1.04
220	0.40	0.45	0.50	0.56	0.61	0.68	0.74	0.80	0.86
240	0.36	0.40	0.44	0.49	0.53	0.59	0.64	0.69	0.73

1 Btu/hr·ft·°F = 1.73 W/mK

Thermal Conductivity (Btu/hr·ft·°F)

Temp, °F	Glycol percent by volume								
	20%	25%	30%	35%	40%	45%	50%	55%	60%
-30									0.171
-20							0.188	0.181	0.174
-10							0.191	0.184	0.176
0					0.211	0.203	0.194	0.186	0.178
10			0.235	0.225	0.215	0.206	0.196	0.188	0.179
20	0.262	0.251	0.239	0.229	0.218	0.209	0.199	0.190	0.181
30	0.267	0.255	0.243	0.233	0.222	0.212	0.201	0.192	0.183
40	0.272	0.260	0.247	0.236	0.225	0.215	0.204	0.194	0.184
50	0.277	0.264	0.251	0.239	0.227	0.217	0.206	0.196	0.186
60	0.281	0.268	0.254	0.242	0.230	0.219	0.208	0.198	0.187
70	0.285	0.272	0.258	0.246	0.233	0.222	0.210	0.199	0.188
80	0.289	0.275	0.261	0.248	0.235	0.223	0.211	0.200	0.189
90	0.292	0.278	0.263	0.250	0.237	0.225	0.213	0.202	0.190
100	0.295	0.281	0.266	0.253	0.239	0.227	0.214	0.203	0.191
120	0.298	0.283	0.268	0.255	0.241	0.228	0.215	0.204	0.192
140	0.306	0.290	0.274	0.260	0.245	0.232	0.218	0.206	0.194
160	0.309	0.293	0.277	0.262	0.247	0.234	0.220	0.207	0.194
180	0.312	0.296	0.279	0.264	0.249	0.235	0.221	0.208	0.195
200	0.314	0.297	0.280	0.265	0.249	0.235	0.221	0.208	0.194
220	0.314	0.297	0.280	0.265	0.249	0.235	0.220	0.207	0.194

1 Btu/lb_m·°F = 4,186 J/kg·°C

Specific Heat (Btu/lb·°F)

Temp, °F	Glycol percent by volume								
	20%	25%	30%	35%	40%	45%	50%	55%	60%
-30									
-20									0.799
-10									0.804
0							0.855	0.832	0.809
10					0.898	0.879	0.859	0.837	0.814
20			0.936	0.919	0.902	0.883	0.864	0.842	0.82
30	0.966	0.952	0.938	0.922	0.906	0.887	0.868	0.847	0.825
40	0.968	0.955	0.941	0.925	0.909	0.891	0.872	0.851	0.830
50	0.970	0.957	0.944	0.929	0.913	0.895	0.877	0.856	0.835
60	0.972	0.960	0.947	0.932	0.917	0.899	0.881	0.861	0.840
70	0.974	0.962	0.950	0.935	0.920	0.903	0.886	0.866	0.845
80	0.976	0.965	0.953	0.939	0.924	0.907	0.890	0.870	0.850
90	0.979	0.968	0.956	0.942	0.928	0.911	0.894	0.875	0.855
100	0.981	0.970	0.959	0.945	0.931	0.915	0.899	0.880	0.861
120	0.985	0.975	0.965	0.952	0.939	0.924	0.908	0.890	0.871
140	0.989	0.980	0.970	0.958	0.946	0.931	0.916	0.899	0.881
160	0.993	0.985	0.976	0.965	0.953	0.939	0.925	0.908	0.891
180	0.996	0.989	0.982	0.972	0.961	0.948	0.934	0.918	0.902
200	1.000	0.994	0.988	0.978	0.968	0.956	0.943	0.928	0.912
220	1.003	0.999	0.994	0.985	0.975	0.963	0.951	0.937	0.922
240	1.007	1.003	0.999	0.991	0.982	0.971	0.960	0.946	0.932

1 lb_m/ft³ = 16 kg/m³

Density (lb/ft³)

Temp, °F	Glycol percent by volume								
	20%	25%	30%	35%	40%	45%	50%	55%	60%
-30									67.05
-20							66.46	66.70	66.93
-10							66.35	66.58	66.81
0					65.71	65.97	66.23	66.46	66.68
10			65.00	65.30	65.60	65.86	66.11	66.33	66.54
20	64.23	64.57	64.90	65.19	65.48	65.73	65.97	66.18	66.38
30	64.14	64.47	64.79	65.07	65.35	65.59	65.82	66.02	66.22
40	64.03	64.35	64.67	64.94	65.21	65.44	65.67	65.86	66.05
50	63.92	64.23	64.53	64.80	65.06	65.28	65.50	65.69	65.87
60	63.79	64.09	64.39	64.65	64.90	65.12	65.33	65.51	65.68
70	63.66	63.95	64.24	64.49	64.73	64.94	65.14	65.31	65.47
80	63.52	63.80	64.08	64.32	64.55	64.75	64.95	65.11	65.26
90	63.37	63.64	63.91	64.14	64.36	64.55	64.74	64.89	65.04
100	63.20	63.47	63.73	63.95	64.16	64.35	64.53	64.67	64.81
120	62.85	63.09	63.33	63.54	63.74	63.90	64.06	64.19	64.32
140	62.46	62.68	62.90	63.09	63.27	63.42	63.57	63.68	63.79
160	62.03	62.23	62.43	62.60	62.76	62.90	63.03	63.13	63.22
180	61.56	61.74	61.92	62.07	62.22	62.34	62.45	62.53	62.61
200	61.05	61.21	61.37	61.50	61.63	61.73	61.83	61.90	61.97
220	60.50	60.64	60.78	60.89	61.00	61.09	61.17	61.23	61.28
240	59.91	60.03	60.15	60.25	60.34	60.41	60.47	60.51	60.55

1 psi = 6,895 Pa = 0.069 bar = 0.0681 atm = 51.7 mmHg = 21.7 inH₂O

Vapor Pressure (psia)

Temp, °F	Glycol percent by volume								
	20%	25%	30%	35%	40%	45%	50%	55%	60%
100	0.9	0.9	0.9	0.9	0.9				
110	1.9	1.6	1.2	1.2	1.2	1.2	1.1	1.1	1.0
120	1.7	1.7	1.6	1.5	1.5	1.5	1.5	1.5	1.4
130	2.2	2.2	2.1	2.1	2.0	2.0	1.9	1.9	1.8
140	2.8	2.8	2.7	2.7	2.6	2.6	2.5	2.4	2.3
150	3.6	3.6	3.5	3.5	3.4	3.4	3.2	3.0	3.0
160	4.6	4.5	4.4	4.4	4.3	4.2	4.1	4.0	3.8
170	5.8	5.8	5.6	5.4	5.4	5.3	5.2	5.0	4.8
180	7.2	7.1	7.0	6.9	6.7	6.6	6.5	6.2	5.9
190	9.0	8.9	8.7	8.5	8.3	8.2	8.1	7.8	7.4
200	11.0	10.9	10.7	10.5	10.2	10.1	9.9	9.5	9.1
210	13.5	13.5	13.1	12.8	12.5	12.3	12.1	11.6	11.1
220	16.4	16.4	15.9	15.6	15.2	15.0	14.8	14.2	13.6
230	19.8	19.5	19.2	18.8	18.4	17.8	17.8	17.1	16.4
240	23.8	23.4	23.0	22.5	22.0	21.7	21.4	20.6	19.7
250	28.4	27.9	27.4	26.9	26.3	26.0	25.6	24.6	23.5

Product Disclaimer

The information contained in this entire publication is presented in good faith at “no charge” and is believed to be correct as of the date indicated. No representations or warranties are made as to its completeness or accuracy. The information listed is supplied upon the condition that the persons receiving it will make their own determination as to its suitability for their purposes prior to use. In no event will the seller be responsible for damages of any nature whatsoever resulting from the use of, or reliance upon, this information or the product to which this information refers. Nothing contained on this page is to be construed as a recommendation to use the product, process, equipment or formulation in conflict with any patent. No representation or warranty, expressed or implied, is made that the use of this product will not infringe any patent.

No representations or warranties, either expressed or implies, of merchantability, fitness for a particular purpose or for any other nature are made with respect to the information, or the product to which the information refers.

Contact Information

Corporate Headquarters

Dynalene, Inc.
5250 West Coplay Road
Whitehall, Pennsylvania 18052
Phone: 610-262-9686 / 1-877-244-5525
Fax: 610-262-7437
Email: info@dynalene.com
Website: www.dynalene.com

Midwest Location

248 Beinoris Dr
Wood Dale, IL 60191
Phone: 1-855-216-7639
Email: centralsales@dynalene.com

West Location

1701 S 5350 W
Salt Lake City, UT 84104
Phone: 1-877-244-5525
Email: westsales@dynalene.com

Published July 2020